

# Cathtip 400 Series

## **SEMI-AUTOMATED HOLE DRILLING MACHINE**

The 400 Series is a precision hole drilling machine that delivers results to the highest industry hole quality standards and is custom built to suit your application's specifications, including:

- Hole sizes down to 0.015"
- Multi-lumen configurations ranging from 2-8+ lumens (able to precisely locate & perforate individual lumen)
- · Materials from soft silicones to harder polymers



The CATHTIP proprietary Flow Thru<sup>™</sup> Hollow Drill's refined process control, and manufacturing excellence have made its machines a staple of most major catheter production clean rooms.

#### **KEY FEATURES**

- Flow  $\mathsf{Thru}^\mathsf{TM}$  core evacuation
- Razor sharp cutting edges drill edge diameter sharpened to +/-0.0007"
- · Burr-free holes
- Long drill life hardened SS440C
- · Tool less drill change
- · Custom design setup & processes
- · On-site support and training
- · Safety light curtain

#### UNIVERSAL SPECIFICATIONS

Motion: Stepper

Power: 100-240 AC at 50/60Hz

Air: 100psi max. 5cfm
Interface: Touchscreen
Dimensions: 31" x 18"x 12"

Weight: 60lbs

### **SOLUTION FLEXIBILITY**

- Multi-lumen configurations from 2-8+ lumens
- Holes sizes down to 0.015
- Up-to 4 holes per second

- 1.5" OE
- Collet-style drill head for punches & ejector pin (optional)



Cathtip is proud to be an MMT company - the sole source for automated, process-driven medical manufacturing.

Medical Manufacturing Technologies (MMT) brings together applications expertise, technical solutions, and aftermarket support to revolutionize medical device manufacturing. **Learn more at mmt-inc.com**.