

Accu-Feed LTD

LOW TENSION DEREELER

The Accu-Feed LTD Low Tension Dereeler is designed to provide constant strain, low tension payout of tubing to an Accu-Cut or other machine for high volume, critical tolerance manufacturing operations. It features a low mass, nonstatic proportional speed dancer arm. The LTD is torque-limited for safety and does not require any electrical connection to its host machine.



KEY FEATURES

- · Designed for high-volume, critical tolerance manufacturing
- Precision ball-bearing construction for low dancer arm friction
- · Torque-limited for safety

- · Communicates with Accu-Cut machines
- Incorporates static-reducing technology for cleanliness

SPECIFICATIONS

Speed: 120rpm

Maximum OD: 0.25" (6.4mm)

Maximum spool diameter: 17.75" (0.45m)

Maximum spool width: 10" (0.25m)

Maximum spool weight: 12 lbs. (5.4kg)

Power: 100-240VAC at 50/60Hz

Dimensions: 30" x 15" x 20" (75" x 40" x 50" cm)

Weight: 20 lb. (9kg)



SYNEO is proud to be an MMT company - the sole source for automated, process-driven medical manufacturing.

Medical Manufacturing Technologies (MMT) brings together applications expertise, technical solutions, and aftermarket support to revolutionize medical device manufacturing. **Learn more at mmt-inc.com**.